

Credit(s) earned on completion of this course will be reported to American Institute of Architects (AIA) Continuing Education Session (CES) for AIA members.

Certificates of Completion for both AIA members and non-AIA members are available upon request.

This course is registered with AIA CES for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product.

Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.

#### **Today's Presentation** Course Description: This course explores: While managing energy use and costs has always been considered an important objective of any facilities management organization, the impact of spiraling energy costs has made this issue more important now than ever. Key to managing energy costs is knowing where, when, and how energy is being used. We will discuss various meters,

methods, and strategies for collecting your energy information Learning Objectives:

1. How to pick a meter 2. How to collect the meter outputs 3. How to convert data into information

Continuing

AIA Continuing Education







# Terminology (cont.)

- > Error: The disagreement between a measurement and the true or
- accepted value Bias: A systematic (built-in) error which shifts all measurements by a ۶ certain amount.
- Instrument Range: The interval between the minimum and maximum ۶ values of the measured variable in which the instrument is accurate
  - Volumetric Flow Rate: The flow of the fluid measured as:  $q = A \times V$

- where:
  - q = volumetric flow, ft<sup>3</sup>/min, m<sup>3</sup>/sec, gal/min, etc. A = area of the pipe, in<sup>2</sup>, cm<sup>2</sup>, etc
- V = velocity, f/min, m/sec, etc.
  Mass or Energy Flow Rate: The actual quantity or energy of fluid, i.e. pounds per hour, BTU/min. tons, etc. Requires knowledge of fluid and its properties. For example:

A cubic foot of air weighs about .075 lbs.; a cubic foot of water weighs about 825 times as Al-cubic much, 62 lbs. Education Provider

≻





















Vortex Vortex meters operate on the principle that when a nonstreamlined object is placed in the middle of a flow stream, a series of vortices are shed alternately downstream of the object (Von Karman vortex street). The frequency of the vortex shedding is directly proportional to the velocity of the fluid flow.



#### Electromagnetic

Magnetic flow meters are based on Faraday's Law of Magnetic Induction. In a magnetic flow meter, the liquid acts as a conductor as it flows through the pipe. This induces a voltage which is proportional to the average flow velocity - the faster the flow rate, the higher the voltage. This voltage is picked up by sensing electrodes mounted in the meter tube and sent to the transmitter which takes the voltage and calculates the flow rate based on the cross sectional area of the meter









Flow meter Characteristics Comparison Sheet										
Flow meter Element	Recommended Service	Turndown	Pressure Loss	Typical Accuracy(%)	Required Upstream pipe diameters	Viscosity Effect	Relative Cost			
Orifice	Clean, dirty fluids; some slurries	4 to 1	Medium	±2 to ±4 of full scale	10 to 30	High	Low			
Venturi tube	tube Clean, dirty and viscous fluids; some slurries		Low	±1 of full scale	5 to 20	High	Medium			
Flow nozzle	Clean and dirty fluids	4 to 1	Medium	±1 to ±2 of full scale	10 to 30	High	Medium			
Pitot tube	Clean fluids	3 to 1	Very low	±3 to ±5 of full scale	20 to 30	Low	Low			
Elbow meter	Clean, dirty fluids; some slurries	ome 3 to 1		±5 to ±10 of full scale	30	Low	Low			
Target meter	Clean, dirty viscous fluids; some slurries	10 to 1	Medium	±1 to ±5 of full scale	10 to 30	Medium	Medium			
Variable area	Clean, dirty viscous fluids	10 to 1	Medium	±1 to ±10 of full scale	None	Medium	Low			
Positive Displacement	Clean, viscous fluids	10 to 1	High	±0.5 of rate	None	High	Medium			
Turbine	Clean, viscous fluids	20 to 1	High	±0.25 of rate	5 to 10	High	High			
Vortex	Clean, dirty fluids	10 to 1	Medium	±1 of rate	10 to 20	Medium	High			
Electromagnetic	Clean, dirty, viscous conductive fluids and slurries	40 to 1	None	±0.5 of rate	5	None	High			
Ultrasonic (Doppler)	Dirty, viscous fluids and slurries	10 to 1	None	±5 of full scale	5 to 30	None	High			
Ultrasonic (Transit Time)	Clean, viscous fluids	20 to 1	None	±1 to ±5 of full scale	5 to 30	None	High			
Mass (Coriolis)	Clean, dirty viscous fluids; some slurries	10 to 1	Low	±0.4 of rate	None	None	High			
Mass (Thermal)	Clean, dirty, viscous fluids; some slurries	10 to 1	Low	±1 of full scale	None	None	High			
Continuing Education Provider										



# Metering Compound Values

for reference Some commonly metered values require multiple inputs and must be calculated, e.g.

- Chilled water: Tons or BTU/hr; requires volumetric flow, supply and return temperatures ( $\Delta T$ ), density compensation generally not required •
- Hot Water: BTU/hr; same as chilled water
  Steam Flow: Pounds/hr or BTU/hr; requires density compensation using temperature, pressure, and heat content. Some meters can do this dynamically, but most use static values.
- Liquid Fuel Mass or Energy Flow: Natural gas or fuel oils; requires density compensation using temperature, pressure, and heat content.
- Solid Fuel Mass or Energy Flow: Coal or wood; requires mass and heat content .

Continuing Education

### Monitoring

Collecting and organizing the data for use

- Manual Data Collection
  - Assign responsibility (who)
  - Locate all meters to be read (where)
  - Learn how to read the meters (how)
  - Determine the frequency of data collection (when)
  - Create data collection forms (what)
  - Plan for future automated collection, i.e. use tablets, netbooks, Microsoft Excel or Access.

AIA Continuing Education

# Monitoring

- Automated Data Acquisition
  - The automated retrieval of field data from remote locations to a centralized data storage location.
  - Components include both hardware and \_ software

AIA Continuing Education

#### Monitoring - for reference • Automated Data Acquisition Hardware

- Utomated Data Acquisition Haroware Programmable Logic Controllers (PLCs): Devices located near the sensors that have the capability to collect and process local data for download to a central storage location "Smart" Meters: Devices that contain software that allow them to process, connect and download data directly to the network Network Connection Devices: Interface between the various field device data transfer protocols (Modbus, ControlNet, BacNet, TCP/IP, etc) and the network (phone, wireless, ethernet, etc.) Database Sensers: computer(s) used to store the data for real-time

- Database Servers: computer(s) used to store the data for real-time, historical, and archival use.
- Firewalls: computer(s) used solely to limit access to the servers and data collection network \_
- Workstation(s): other computers that can connect to the database servers to disseminate and process collected data
- Wiring: between field devices internal to building, between buildings. 4-20 mA, Cat5e, RS485, etc. Need to chose whether to use campus WAN or install dedicated network

Continuin













# Verification

- Energy Management Information System (EMIS): Convert DATA into INFORMATION
  - Gather dispersed and disparate production, energy use (both billing and meter) and budget energy data from multiple sites, multiple energy suppliers and different types of energy suppliers.
  - Validate the data and manage missing or erroneous data.
  - Convert the raw data into usable management information, particularly meaningful Key Performance Indicators (KPIs).
  - Generate meaningful reports that include the analysis of trends and exceptions.
  - Distribute the analyses and reports across multiple sites, internally and externally, in a timely fashion.

AIA Continuing Education







Anch	ing carca, v a ⊂a tors_Util	ity	CO ** 2.8						14 .00 4.0			
	A		В	С	_	1	D		E	F	G	н
	Menu	Facility	Report for	: Clark-Reib- Report I Report P	Somer k Date: 'eriod: to	fall Penti 12/14/ 1/1/20 12/31	house /2009 008 1/2008	E Pror	30,000 ation On	square feet		
		Utility	Мах	M	5	A	ivg		fotal	ECAP Ch	eck	BTU/ SQF
	ChW (	Cooling, Tons	229	1	(0)		66	$\square'$	575,957	69,115	MMBTU	230,3
		Meter A	Conco	· Facility Rel				1	575,957		T	Ē
		Meter B	_	And in case of the local division of the loc	-	_	_		-			<u> </u>
	ChW St	Jpply Temp, F		Start Date:	11/22	/2009	1					<u> </u>
	ChW R	aturn Temp, F		End Date:	1.100		-					<u> </u>
	ChW Differe	antial Temp, F		End Date.	12/21	,/2009						<u> </u>
	s	team MMBTU	Select	Ste:				5,	588.379	4,859.460	Klbs	186,2
		Meter A	405	terms School of		and the		5.	588.379			
		Meter B	100	7500 percention	Takager	10	_	á F	-			
		Meter C	Anth	Anapology Anni	Managas	serve	-	4	-			
	S	team Temp, F	Anth	sropology Maxv	vel Musev	.m						
	Electr	icity, kW/kWh	Ban	Juiking Heler Hall				1/	452,053	1,452,053	KWh	165,1
		Meter A	Bask	Medical Science				17	452,053			<u> </u>
		Meter B	BBR	Pavilon Joy Annex				- L.	-			
		Meter C		II Come	-			2 L				
		Meter D		Calc Report		Close	4		-			
				-	-	-		17	.455.72			581,8
NOTE:	If the total cells are yeld	w then the totals har	ve been prorat	ted due to in	sufficier	at data.	See the r	cell com	ment.			
				1			10					



















### THIS CONCLUDES THE AMERICAN INSTITUTE OF ARCHITECTS CONTINUING EDUCATION SYSTEMS COURSE

AIA Continuing Education Provider